

AP20 COUNTER



- 8 Digit display in DIN-enclosure
96x48 mm
- Supply voltage 10 – 35 V DC
- All in- and outputs optically isolated
- Input for incremental encoders
- RS232
- 2 Digital inputs and 4 digital outputs
- 12 Programmable cams / 4 outputs
- 24 Programmable nominal values
- 12 Programmable Cams over 4 outputs
(cycle time 250μS)
- Programmable analog output (16 bit)
(with teach function)
- All connectors removable

AP20 COUNTER

Table of contents

1	Introduction	4
1.1	General	4
1.2	Important information	4
1.3	EMC	4
1.4	Definitions	4
1.4.1	<i>Display units AWE</i>	4
1.4.2	<i>Parameter number</i>	5
1.4.3	<i>Notation</i>	5
1.4.4	<i>Edges</i>	5
2	Operation	6
2.1	Key functions	6
2.2	Key functions in programming mode	7
2.3	Display functions	8
2.3.1	<i>Status functions</i>	8
2.3.2	<i>Error messages</i>	8
2.3.3	<i>Survey of error messages</i>	9
3	Programming	10
3.1	Automatic mode	10
3.1.1	<i>Monitor function</i>	11
3.1.2	<i>Displaying the type number</i>	11
3.1.3	<i>Displaying the software-version</i>	12
3.1.4	<i>Status in- and outputs</i>	13
3.2	Changing nominal values	14
3.3	Changing parameters	15
3.3.1	<i>Menus</i>	15
3.3.2	<i>Input parameters</i>	16
4	Functions	17
4.1	Actual position	17
4.2	Velocity measurement	17
4.3	Multiplicator	17
4.4	Power failure protection	18
4.5	Edge multiplication (counter input)	19
4.6	Preset	20
4.6.1	<i>Preset using input 1 or 2</i>	20
4.6.2	<i>Preset using service parameter P[207]</i>	20
4.6.3	<i>Preset using front keys</i>	20
4.7	Counting range	21
4.8	ASCII protocol	22
4.8.1	<i>Overview functions</i>	22
4.8.2	<i>General</i>	23
4.8.3	<i>Functions</i>	24
4.8.4	<i>Error messages</i>	27
4.9	Analog output	28
4.9.1	<i>Voltage output</i>	28
4.9.2	<i>Current output</i>	29
4.9.3	<i>Example programming voltage output</i>	30
4.10	Teach function analog output	30
4.11	Cams	31
4.11.1	<i>General</i>	31
4.11.2	<i>Cam with start- and end-value</i>	31
4.11.3	<i>Greater than or equal to limit value</i>	31
4.11.4	<i>Smaller than or equal to limit value</i>	32
4.11.5	<i>Start/stop cam</i>	32
4.11.6	<i>Output "Cams active"</i>	32

AP20 COUNTER

5 Parameters	33
5.1 Menu 1 Config	33
5.2 Menu 2 Actual	34
5.3 Menu 3 Serial	35
5.4 Menu 4 Input	36
5.5 Menu 5 Output	37
5.6 Menu 6 Cam	38
5.6.1 Submenu 6.1 ... 6.12 CA1...12	38
5.7 Menu 7 Analog output	38
5.7.1 Submenu 7.1 Config	38
5.7.2 Submenu 7.2 DA-U (voltage)	39
5.7.3 Submenu 7.3 DA-I (current)	39
5.8 Overview parameters	40
6 Connections	41
6.1 Overview clamp connections	41
6.2 Supply	42
6.3 Counting input	43
6.4 Encoder 5V with inverted signals	43
6.5 Encoder 5V without inverted signals	44
6.6 Encoder 10 – 30V	44
6.7 Digital inputs	45
6.8 Digital outputs	45
6.9 RS232	46
6.10 Analog output	46
7 Technical specifications	47
7.1 Specifications	47
7.2 Typekey	48
7.3 Dimensions AP20	48
7.4 Dimensions EMC bracket type EMC-B02	49
7.4.1 Connections RS232 on 9P sub-D connector	50
7.5 Dimensions protective hood type CDS-B02	50

AP20 COUNTER

1 Introduction

1.1 General

With the microcontroller based AP20 it is possible to connect the following encoder types:

- Incremental with quadrature (two 90°) signals
- Incremental with pulssignal and directionsignal

It is standard equipped with 2 digital inputs and 4 digital outputs, all free programmable. The AP20 features a RS232 communication port and a analog output.

With the 12 programmable cams several functions can be realized like limit detection.

Another feature of the AP20 is the memory for the nominal values. The 24 programmable values can be used to determine the positions of the cams.

The microcontroller reads the actual sensor value and calculates the display-value and the actual velocity. A programmable power failure protection makes sure that the actual value is stored in an EEPROM. The AP20 is configurable for numerous applications by adjusting its parameters.

The AP20 can be programmed with the DST2 PC-based software.

1.2 Important information

- The AP20 is a high-tech electronic product. To ensure safety and a correct functioning of the product it is important that only qualified specialists will install and operate the AP20.
- If through a failure or fault of the AP20 an endangering of persons or damage to plant is possible, this must be prevented using additional safety measures. These must remain operational in all possible modes of the AP20.
- Necessary repairs to the AP20 are only to be carried out by the manufacturer.

1.3 EMC

To ensure the best possible electromagnetic compatibility, it is recommended to pay attention to shielding and grounding the AP20:

- Shielding on both sides and with the largest possible contact area.
- Keep wiring as short as possible.
- Earth-connections should be short and with the highest possible wiring-diameter.
- Signal-cables and supply-cables must be separated.
- The EMC-bracket type EMC-B02 should be used.

1.4 Definitions

1.4.1 Display units AWE

The display units, referred to as AWE, is the value shown on the display without regarding the decimal point. The decimal point is only used for the comfort of the operator, but has no functional meaning.

(display = 347.4 >> AWE = 3474)

AP20 COUNTER

1.4.2 Parameter number

A parameter number is always shown in the format P[xxx]. It is possible that a parameter number appears in more than one menu.

1.4.3 Notation

Values can be displayed in different notations like binary or hexadecimal. The character behind the value shows in which notation the value is represented:

100D	<u>D</u> ecimal
238H	<u>H</u> exadecimal
244G	<u>G</u> ray
10010011B	<u>B</u> inary

for example 220D = DCH = 11011100B

1.4.4 Edges

L→H : rising edge (low to high)

H →L : falling edge (high to low)

AP20 COUNTER

2 Operation

2.1 Key functions



[P] key

- Cycle through monitoring displays
- Activate programming mode (in combination with other keys)



[+1] key

- View type number



[Cursor] key

- View software version
- View custom software version (in combination with the [Enter] key)



[Enter] key

- View status of inputs and outputs

AP20 COUNTER

2.2 Key functions in programming mode



[P] key

- one step back in menu
- discontinue programming mode
- discontinue changing nominal values/parameters (edit mode)
- LED is on when programming mode is active



[+1] key

- cycle through menu
- increase nominal value- / parameter number
- increase digit (in edit mode)



[Cursor] key

- activate edit mode
- move one digit to the left (in edit mode)




[Enter] key

- enter a submenu or parameter
- increase nominal value-/parameter number
- store a changed value
- clear value, hold down [Cursor] button (edit mode)

AP20 COUNTER

2.3 Display functions

2.3.1 Status functions





2.3.2 Error messages

There are two groups of errors:

- Parameter errors (error numbers 0...499, preceded by a "P")
- General error (error numbers from 500 and up)

Example:



AP20 COUNTER

2.3.3 Survey of error messages

Error no:

000...499 Parameter error is displayed as PXXX on the display.

700 = Reference value P[003] $\geq$ Counting range P[004]

716 = Umin $\geq$ Umax (analog output)

717 = Imin $\geq$ Imax (analog output)

720 = Changelock nominal values active

721 = Changelock parameters active

732 = Function input-2 not valid (equal to input-1)

Error messages for cams (last 2 digits = cam number)

10xx

Counting range active

Length cam = 0 (if counting range is active)

No counting range active or source for cam is velocity

Length cam $\leq$ 0

11xx Length cam $\leq$ Hysteresis

12xx Hysteresis too large or length cam too large ($2 * \text{Hysteresis} + \text{Length} \geq \text{Counting range}$)

13xx cam begin and/or cam end outside counting range (incl. hysteresis)

Error messages ASCII

er 1 = parity error

er 2 = frame error

er 3 = overflow error

er 4 = buffer overrun

er 5 = number invalid

er 6 = data invalid (outside min/max value)


er 7 = programming mode parameters/nominal values active

AP20 COUNTER

3 Programming

There are three different modes of operation:

- Automatic mode
- Programming mode for nominal values
- Programming mode for parameters



3.1 Automatic mode


In the automatic mode, depending on the type of sensor, the increments are counted or the absolute position is read and the result is shown on the display as the actual value. The velocity is calculated and can be visualized as well.

AP20 COUNTER

3.1.1 Monitor function


In automatic mode different variables can be displayed. By using the [P] key one can cycle through the different pages:

- Actual position
- Actual velocity
- Voltage or current of the DA (analog out)




Parameter P[208] determines which option is visible after start-up.

3.1.2 Displaying the type number




AP20 COUNTER

3.1.3 Displaying the software-version



AP20 COUNTER

3.1.4 Status in- and outputs



Inputs

1 = input-1
2 = input-2
A = input K1
B = input K2

Outputs


7 = output-1
8 = output -2
9 = output -3
10 = output -4

Outputs

18 = Cams active

AP20 COUNTER


3.2 Changing nominal values




Access to nominal values



Select nominal values



Changing values



*) keep pressed

AP20 COUNTER

3.3 Changing parameters

3.3.1 Menus


The parameters are displayed in different menus and submenus:

- 1 ConFiG
- 2 ActuAL
- 3 SEriAL
- 4 InPut
- 5 OutPut
- 6 Cam
 - 6.1 CA1
 -
 -
 - 6.12 CA12
- 7 An out
 - 7.1 ConFG.
 - 7.2 dA-U
 - 7.3 dA-I


*Example:
PAr. 6.1.1 means
menu 6, submenu 1, parameter 1*

AP20 COUNTER


3.3.2 Input parameters




Access parameters




Menu selection




Submenu selection



Selecting parameters



Changing parameters



*) keep pressed down

AP20 COUNTER

4 Functions

4.1 Actual position

The actual position shown on the display.

$$\text{Actual position} = \text{Counter} \times \text{FL} \times \text{dir} \times \frac{\text{Mt}}{\text{Mn}}$$

FL	=	edgemultiplier	P[210]	
Mt	=	multiplicator numerator	P[000]	
Mn	=	multiplicator denominator	P[001]	
dir	=	direction (x1 or x -1)	P[211]	

4.2 Velocity measurement

The velocity measurement is always active and delivers the actual speed in AWE/s.

Two parameters are necessary to configure the measurement:

P[088] = measuring time [AWE/s]

The smaller the measurement time the more dynamic the velocity measurement will be. This time is also the refreshment-interval on the display.

P[202] = integrator

The number of cycles are programmed. The average velocity (unit =AWE/s) of the programmed cycles is calculated.

Example:

Measurement time = 50ms, integrator = 10.

The actual velocity will be refreshed every 50 ms and is the average velocity during the last 10 measurements.

4.3 Multiplicator

By using the multiplicator it is possible to convert the counter-value to display-units (AWE).

Example:

Encoder with 90° shifted signal and 1024 increments/revolution will have 4096 edges/revolution. If the desired value in the display is 360,0 (= 3600 AWE), the multiplicator will be 3600/4096 = 0,87890625.

It is possible to program the exact values (3600 and 4096) instead of the fraction.

Multiplicator (numerator) P[000] = 3600

Multiplicator (denominator) P[001] = 4096

Through P[203] it is possible to adjust the decimal point.

AP20 COUNTER

4.4 Power failure protection

If $P[206] = 1$ then the actual position of the AP20 will be stored in EEPROM when power is shut down. After power up this value will be restored. When the writing is finished the display shows the following.




AP20 COUNTER


4.5 Edge multiplication (counter input)

There are two possibilities for the counter input:

V-signal x4: edge multiplication x4, 90° shifted encoder signals.



S-signal x2: edge multiplication x2, encoder signal with directional signal.



AP20 COUNTER

4.6 Preset

The preset function can be used in 3 ways:


- Using inputs 1 or 2 (in combination with reference coarse)
- Using parameter service functions P[207]
- Using front keys

4.6.1 Preset using input 1 or 2

The function preset is used to set the actual value to a programmed value, stored in P[003].

The value will be set in case of an active edge from the reference fine signal (Input 1 or 2).

If reference coarse has been activated ($P[213] \neq 0$) one of the inputs has to be programmed to **"1 – Reference Coarse"**.



4.6.2 Preset using service parameter P[207]

When P[207] has the value 111 then the actual position is preset with the value of P[003] when exiting the programming mode. The parameter reference coarse P[213] and direction reference fine P[209] have no function.

After executing this function parameter P[207] will have the value 0 again.

4.6.3 Preset using front keys

The function preset can be executed with the key combination [Enter] + [P].

Holding down the [Enter] key and push the [P] key one time. Then the actual position is preset with the value of P[003]. The parameter reference coarse P[213] and direction reference fine P[209] have no function.

This function is active when: P[212] = variant **"3 front keys"**

AP20 COUNTER

4.7 Counting range

The counting range used by the counter can be limited. The number of increments is programmed, ignoring the decimal point.

Counting range P[004]

0 = function not active

1 ... counting range

Example:

Incremental encoder, 90° shifted signals, 1000 pulses/rev. and 1,5 rev. = 360,0 degrees.

1000 pulses/rev. is equal to 4000 increments/rev. (edge multiplication x4).

3600 AWE $\Leftrightarrow 1,5 \times 4000 = 6000$ increments


Multiplicator (numerator) P[000] = 3600

Multiplicator (denominator) P[001] = 6000

Counting range P[004] = 6000 increments

At P[203] it is possible to program the use of a decimal point.

Display will show:



359,8 ... 359,9 ... 0,0 ... 0,1 ... 0, 2

AP20 COUNTER

4.8 ASCII protocol

The serial port of the AP20 is able to work with an ASCII protocol.

Using the ASCII protocol, actual values can be read, parameters and nominal values can be stored and read, the status of the digital inputs and outputs can be monitored etc.

4.8.1 Overview functions

sc	select AP20
r0	Read actual position (AWE)
r1	Read actual velocity (AWE/s)
r2	Read actual voltage analog output (0,1mV units)
r3	Read actual current analog output (0,1 mA units)
ri	Read status inputs
ru	Read status outputs
rk	Read status input K1 en K2
wu	Write outputs
rp	Read parameter
wp	Write parameter (Only EEPROM)
rs	Read nominal value
ws	Write nominal value (RAM + EEPROM)
rx	Read software version
rt	Read type number
rh	Read hardware version
rf	Read error number
rn	Read status bits
bp	Load and activate

AP20 COUNTER


4.8.2 General

Through the ASCII protocol it is possible to communicate with the AP20.


Send: Data from PC, PLC → AP20

Receive: Data from AP20 → PC, PLC

Connection without EMC bracket



Connection with EMC bracket (EMC-B02)



Send structure:

Functioncode (space) [argument 1](space)[argument 2] <CR>

Receive structure:

Functioncode (space) [argument1](space)[argument 2] <CR> <LF>

Functioncode (space) [argument1] [argument 2].

Argument 1 and 2 are depending on the function and are separated by a space.

Example:

wp 20 250 (write value 250 to parameter 20)

AP20 COUNTER

4.8.3 Functions

sc Select AP20

send:	sc xx
receive:	sc xx
transmitting parameter:	Unit Id number

The AP20 with the unit Id number is selected, all consecutive commands are relevant for this unit. An AP20 with unit Id number 0 will always respond.

r0 Read actual position (AWE)

send:	r0
receive:	r0 xxxxxxxx
transmitting parameter:	none

r1 Read actual velocity (AWE/s)

send:	r1
receive:	r1 xxxxxxxx
transmitting parameter:	none

r2 Read actual voltage analog output (0,1mV units)

send:	r2
receive:	r2 xxxxxxxx
transmitting parameter:	none

r3 Read actual current analog output (0,1 mA units)

send:	r3
receive:	r3 xxxxxxxx
transmitting parameter:	none

ri Read status inputs

send:	ri
receive:	ri xxx
transmitting parameter:	none

B0 = input-1
 B1 = input-2
 B2 = 0
 B3 = 0
 B4 = 0
 B5 = 0
 B6 = 0
 B7 = 0

Example:

ri 03 gives the following answer:
 03 → 03H, 0000 0011 B
 input-1 = "1"
 input-2 = "1"

AP20 COUNTER

ru Read status outputs

send: **ru**
 receive: **ru xxx**
 transmitting parameter: none

B0 = output-1
 B1 = output-2
 B2 = output-3
 B3 = output-4

rk Read status input K1 and K2

send: **rk**
 receive: **rk x**
 transmitting parameter: none

B0 = K1 or counting direction
 B1 = K2 or counting pulse

wu Write outputs

(only valid for outputs with "ASCII protocol" selected)

send: **wu xxx**
 receive: **wu xxx**
 transmitting parameter: data for output

B0 = output-1
 B1 = output-2

Example:
Output-2 should be set to "1":
00000010B = 02H = 02D
 send: **wu 10**
 receive: **wu 10**

rp Read parameter

send: **rp xxx**
 receive: **rp xxxxxxxx**
 transmitting parameter : parameter number

Example reading parameter P[004]
 send: **rp 4**
 answer: **rp 4 10000**

wp write parameter (only EEPROM)

send: **wp xxx xxxxxxxx**
 receive: **wp xxx xxxxxxxx**
 transmitting parameter: parameter number and parameter value

Example writing parameter P[004] with value 185000
 send: **wp 4 185000**
 answer: **wp 4 185000**

Parameter will be stored to EEPROM but is not yet active.

AP20 COUNTER

rs Read nominal value

send: **rs xx**
 receive: **rs xx xxxxxxxx**
 transmitting parameter: nominal value

Example reading nominal value 22

send: **rs 22**
 answer: **rs 22 72500**

ws Write nominal value (RAM + EEPROM)

send: **ws xx xxxxxxxx**
 receive: **ws xx xxxxxxxx**
 transmitting parameter: nominal value number and nominal value

Example writing nominal value 22 with value 195200

send: **wp 22 195200**
 answer: **wp 22 195200**

rx Read software version

send: **rx**
 receive: **rx SW Vxx.xx SSW xx.xx**
 transmitting parameter: none

SW = standard software version
 SSW = special software version

Example:

send: **rx**
 answer: **rx SW 4.02 SSW 1.00**

rt Read type number

send: **rt**
 receive: **rt AP20-DA**
 transmitting parameter: none

Example:

send: **rt**
 answer: **rt AP20-DA**

rh Read hardware version

send: **rh**
 receive: **rh HW x RV x**
 transmitting parameter: none

AP20 COUNTER

rf Read error number

send:	rf
receive:	rf xxxx
transmitting parameter:	none

When -1 returns no error is present.

<i>Example:</i>	
send:	rf
answer:	rf 004 (parameter error)
or	
answer:	rf -1 (no error)

rn Read status bits

send:	rn
receive:	rn xxx
transmitting parameter:	none

B0 = cams active (started)
B1 = reference set

bp Load and activate

send:	bp
receive:	bp xxx
transmitting parameter:	none

In case of an error the error number will be returned (-1 is no errors).

<i>Example:</i>	answer: bp -1 (no errors)
	answer: bp 20 (error parameter 20)

4.8.4 Error messages

In case of an error the AP20 will send an error message followed by an error number.

overview error messages

- er 1** = parity error
- er 2** = frame error
- er 3** = overflow error
- er 4** = buffer overrun
- er 5** = number invalid
- er 6** = data invalid (for example outside min/max range)
- er 7** = programming mode parameters/nominal values still active
- er 8** = function impossible

AP20 COUNTER

4.9 Analog output

The AP20 has an optional, galvanically isolated analog output. Using parameter P[231] it is possible to choose between a current output or a voltage output. The analog output can be used to give out the actual position or velocity (see parameter P[230]).

4.9.1 Voltage output


The voltage output has a resolution of 305 μV and is programmable through P[080] ... P[083].

P[080] = $U_{\min}$ [V] (input in 0,0001V units)

P[081] = $U_{\max}$ [V] (input in 0,0001V units)

P[082] = S- $U_{\min}$ [AWE] (actual value at $U_{\min}$)

P[083] = S- $U_{\max}$ [AWE] (actual value at $U_{\max}$)



AP20 COUNTER

4.9.2 Current output


The current output has a resolution of 610 μA and is programmable through P[084] ... P[087].

P[084] = $I_{\min}$ [A] (input in 0,0001mA units)

P[085] = $I_{\max}$ [A] (input in 0,0001mA units)

P[086] = S- $I_{\min}$ [AWE] (actual value at $I_{\min}$)

P[087] = S- $I_{\max}$ [AWE] (actual value at $I_{\max}$)




AP20 COUNTER

4.9.3 Example programming voltage output

- > 0,01 mm units
- > actual position at +9V should be -850,00 mm
- > actual position at -8V should be 1100,00 mm

$P[080] = U_{min} = -8,0000 [V]$
 $P[081] = U_{max} = +9,0000 [V]$
 $P[082] = S-U_{min} = 110000 [AWE]$
 $P[083] = S-U_{max} = -85000 [AWE]$



4.10 Teach function analog output

The value for Smin and Smax can be set by an external input signal. For this function parameter P[234] and or P[235] can be set to variant **"1 Teach via input"**. The function for the input 1...4 can be set to variant **"11 DAC Set Smin"** or variant **"12 DAC Set Smax"**.

On the positive edge of the input signal the teach function will be executed.

The value of Smin or Smax will be stored with the actual position or the actual speed depending on parameter P[230]. The display will show "teach Lo" or "teach hi" for a short time.

AP20 COUNTER

4.11 Cams

4.11.1 General

The AP20 has a maximum of 12 programmable cams divided over a maximum of 4 outputs.


Programmable functions:

- Type
- Cam with start- and end-value
- Greater than or equal to limit value
- Smaller than or equal to limit value
- Source (actual position or actual velocity)
- Nominal value location number for start-, end-, or limit value
- Hysteresis
- Output for cam

Per cam one can choose whether to program the values directly into the parameters or to use a nominal value location number where the values are programmed.


4.11.2 Cam with start- and end-value

Two values are programmed, a start value and an end-value.



4.11.3 Greater than or equal to limit value


Only one limit value needs to be programmed.



AP20 COUNTER

4.11.4 Smaller than or equal to limit value

Only one limit value needs to be programmed.



4.11.5 Start/stop cam

The outputs for the cams can be enabled or disabled. If for one of the inputs 1..6 the function start/stop cams has been chosen.

Start/stop cams with one signal

Input-x = option **"5 start/stop cams"** (high = cams enabled)

Start/stop cams with double signal

Input-x = option **"6 start cams"** (rising edge = enable cams)

Input-x = option **"7 stop cams"** (rising edge = disable cams)

4.11.6 Output "Cams active"

On one of the outputs 1...4 the signal "cams active" can be generated by choosing option **"4 cams active"** (high = cams enabled).

AP20 COUNTER

5 Parameters

General lay-out:

PAR.	PAR Nr:	Possible values (bold is the standard value)
Basic description		
Description of possible values		

5.1 Menu 1 Config

PAR: 1.0.1	P[088]	0 ... 40 ... 2500
Measuring time velocity [AWE/s] (equal to refreshment time display)		
X.XXX (sec) input 0 .. 1.000s		

PAR: 1.0.2	P[202]	0 ... 10 ... 20
Integrator velocity		
Actual velocity is the average from the number of measurements		
0 = not active		
1...20 number of measurements		

PAR: 1.0.3	P[203]	0 ... 6
Number of decimals		
0 = none		
1 = X.X		
2 = X.XX		
3 = X.XXX		
4 = X.XXXX		
5 = X.XXXXX		
6 = X.XXXXXX		

PAR: 1.0.4	P[204]	0 ... 1
Store function		
0 = no function		
1 = display		

PAR: 1.0.5	P[205]	0 ... 2
Store signal		
0 = high active		
1 = low active		

PAR: 1.0.6	P[206]	0 ... 1
Power failure protection		
0 = not active		
1 = active		

PAR: 1.0.7	P[207]	0 ... 123
Service functions		
Only possible to activate through keyboard AP20		
Value is automatically set to 0 after executing the service function		
0 = not active		
123 = set default parameters		
111 = adjusting absolute sensors or preset function counter and freq.		

PAR: 1.0.8	P[208]	0 ... 1
Default monitor function		
Determines the default which is visible after start-up.		
0 = Actual position		
1 = Actual velocity		

AP20 COUNTER

5.2 Menu 2 Actual

PAR: 2.1.1	P[210]	0 ... 1
Signal type and edge multiplication "S-signal X2": K2 is counter and K1 is direction		
0 = V-signal X4 1 = S-signal X2		
PAR: 2.1.2	P[211]	0 ... 1
Counting direction		
0 = no reverse 1 = reverse		
PAR: 2.1.3	P[000]	0 ... 10000 ... 16777215
Multiplier numerator XXXXXXXX		
PAR: 2.1.4	P[001]	0 ... 10000 ... 16777215
Multiplier denominator XXXXXXXX		
PAR: 2.1.5	P[212]	0 ... 3
Reference fine		
0 = no function 1 = rising edge (input 1 or 2) 2 = falling edge (input 1 or 2) 3 = front keys		
PAR: 2.1.6	P[213]	0 ... 2
Reference coarse		
0 = no function 1 = high signal 2 = low signal		
PAR: 2.1.7	P[209]	0 ... 2
Counting direction for setting reference value		
0 = independant from direction 1 = when counting in positive direction 2 = when counting in negative direction		
PAR: 2.1.8	P[003]	-9999999 ... 0 ... 99999999
Reference value 1 -XXXXXXXX (AWE)		
PAR: 2.1.9	P[004]	0 ... 99999999
Counting range (no function when Hold/Reset is active (P[200]) XXXXXXXX (AWE)		

AP20 COUNTER

5.3 Menu 3 Serial

PAR: 3.0.1	P[236]	0 ... 31
Unit address		
XX		
PAR: 3.0.2	P[237]	0 ... 1 ... 4
Baudrate		
0 = 9600		
1 = 19200		
2 = 28800		
3 = 38400		
4 = 57600		
PAR: 3.0.3	P[238]	0 ... 1
Number of stopbits		
0 = 1 Stopbit		
1 = 2 Stopbits		
PAR: 3.0.4	P[239]	0 ... 2
Parity		
0 = none		
1 = odd		
2 = even		
PAR: 3.0.5	P[240]	0 ... 1
Protocol		
0 = no function		
1 = ASCII		

AP20 COUNTER

5.4 Menu 4 Input

INPUT-1

PAR: 4.0.1	P[249]	0 ... 12
------------	--------	----------

Function input-1

- 0 = no function
- 1 = coarse
- 2 = reference fine
- 3 = store
- 4 = error reset SSI (only AP21)
- 5 = start/stop cams
- 6 = start cams
- 7 = stop cams
- 8 = lock input nominal values
- 9 = lock input parameters
- 10 = lock input nominal values + parameters
- 11 = DAC Set Smin
- 12 = DAC Set Smax

INPUT-2

PAR: 4.0.2	P[250]	0 ... 12
------------	--------	----------

Function input-2

XX (see input-1)

AP20 COUNTER

5.5 Menu 5 Output

OUTPUT 1

PAR: 5.0.1	P[252]	0 ... 7
------------	--------	---------

Function output-1

- 0 = cam
- 1 = cam inverted
- 2 = SSI error (high = no error) only AP21
- 3 = Start/Stop error (no magnet or time-out) only AP23
- 4 = reference/adjustment set
- 5 = cams active
- 6 = ASCII protocol
- 7 = Counting direction (high = downwards counting)

OUTPUT-2

PAR: 5.0.2	P[253]	0 ... 7
------------	--------	---------

Function output-2

XX (see output-1)

OUTPUT-3

PAR: 5.0.3	P[254]	0 ... 7
------------	--------	---------

Function output-3

XX (see output-1)

OUTPUT-4

PAR: 5.0.4	P[255]	0 ... 7
------------	--------	---------

Function output-4

XX (see output-1)

AP20 COUNTER

5.6 Menu 6 Cam

5.6.1 Submenu 6.1 ... 6.12 CA1...12

CAM-1...12

PAR: 6.x.1	P[256]...P[267]	0 ... 3
------------	-----------------	---------

Cam function

- 0 = no function
- 1 = range
- 2 = actual position >= limit value
- 3 = actual position <= limit value

PAR: 6.x.2	P[280]...P[291]	0 ... 1
------------	-----------------	---------

Source

- 0 = actual position
- 1 = actual velocity

PAR: 6.x.3	P[304]...P[315]	0 ... 12
------------	-----------------	----------

Source cam begin / limit value
(limit value if cam function = 2 or 3)

- 0 = parameters cam begin
- 1...12 = Nominal value 1...12

PAR: 6.x.4	P[292]...P[303]	0 ... 12
------------	-----------------	----------

Source cam end

- 0 = parameters cam end
- 1...12 = Nominal value 1...12

PAR: 6.x.5	P[007]...P[018]	-9999999 ... 1000 ... 99999999
------------	-----------------	---------------------------------------

Cam begin / limit value
(limit value if cam function = 2 or 3)

-XXXXXXX

PAR: 6.x.6	P[031]...P[042]	-9999999 ... 2000 ... 99999999
------------	-----------------	---------------------------------------

Cam end

-XXXXXXX

PAR: 6.x.7	P[055]...P[066]	0 ... 999999
------------	-----------------	--------------

Hysteresis cam

XXXXXX

PAR: 6.x.8	P[268]...P[279]	0 ... 4
------------	-----------------	---------

Assign cam to output

- 0 = no output
- 1...4 = output 1-4

5.7 Menu 7 Analog output

5.7.1 Submenu 7.1 Config

PAR: 7.1.1	P[231]	0 ... 2
------------	--------	---------

Selection DA output

- 0 = inactive
- 1 = voltage
- 2 = current

PAR: 7.1.2	P[230]	0 ... 1
------------	--------	---------

Selection DA source

- 0 = actual position
- 1 = actual velocity

AP20 COUNTER

5.7.2 Submenu 7.2 DA-U (voltage)

DA PAR 7.2.1...7.2.4 = 0: DA not active

PAR: 7.2.1	P[080]	-100000 ... 99999
------------	--------	-------------------

Umin DA

-XX.XXXX (V)

PAR: 7.2.2	P[081]	-99999 ... 100000
------------	--------	-------------------

Umax DA

-XX.XXXX (V)

PAR: 7.2.3	P[082]	-9999999... -100000 ... 99999999
------------	--------	----------------------------------

S-Umin DA

-XXXXXXXX (AWE)

PAR: 7.2.4	P[083]	-9999999 ... 100000 ... 99999999
------------	--------	----------------------------------

S-Umax DA

-XXXXXXXX (AWE)

PAR: 7.2.5	P[234]	0 ... 1
------------	--------	---------

Source for Smin

0 = parameter Smin

1 = teach by input

PAR: 7.2.6	P[235]	0 ... 1
------------	--------	---------

Source for Smax

0 = parameter Smax

1 = teach by input

5.7.3 Submenu 7.3 DA-I (current)

DA PAR 7.3.1...7.3.4 = 0: DA not active

PAR: 7.3.1	P[084]	-200000 ... 199999
------------	--------	--------------------

Imin DA

-XX.XXXX (mA)

PAR: 7.3.2	P[085]	-199999 ... 200000
------------	--------	--------------------

Imax DA

-XX.XXXX (mA)

PAR: 7.3.3	P[086]	-9999999 ... -200000 ... 99999999
------------	--------	-----------------------------------

S-Imin DA

-XXXXXXXX (AWE)

PAR: 7.3.4	P[087]	-9999999 ... 200000 ... 99999999
------------	--------	----------------------------------

S-Imax DA

-XXXXXXXX (AWE)

PAR: 7.3.5	P[234]	0 ... 1
------------	--------	---------

Source for Smin

0 = parameter Smin

1 = teach by input

PAR: 7.3.6	P[235]	0 ... 1
------------	--------	---------

Source for Smax

0 = parameter Smax

1 = teach by input

AP20 COUNTER


5.8 Overview parameters

<u>No</u>	<u>Description</u>	<u>Menu</u>
[000]	= Multiplier numerator	2.1.3
[001]	= Multiplier denominator	2.1.4
[002]	= no function	
[003]	= Reference value	2.1.8
[004]	= Counting range	2.1.9
[005], [006]	= no function	
[007]...[018]	= Cam begin / limit value	6.1.5...6.12.5
[019]...[030]	= no function	
[031]...[042]	= Cam end	6.1.6...6.12.6
[043]...[054]	= no function	
[055]...[066]	= Hysteresis cam	6.1.7...6.12.7
[067]...[079]	= no function	
[080]	= Umin DA	7.2.1
[081]	= Umax DA	7.2.2
[082]	= S-Umin DA	7.2.3
[083]	= S-Umax DA	7.2.4
[084]	= Imin DA	7.3.1
[085]	= Imax DA	7.3.2
[086]	= S-Imin DA	7.3.3
[087]	= S-Imax DA	7.3.4
[088]	= Measuring time velocity	1.0.1
[089]...[201]	= no function	
[202]	= Integrator velocity	1.0.2
[203]	= Number of decimals	1.0.3
[204]	= Store function	1.0.4
[205]	= Store signal	1.0.5
[206]	= Power failure protection	1.0.6
[207]	= Service functions	1.0.7
[208]	= Default monitor function	1.0.8
[209]	= Counting direction reference fine	2.1.7
[210]	= Input type and edge multiplication	2.1.1
[211]	= Counting direction	2.1.2
[212]	= Reference fine (input 1 or 2)	2.1.5
[213]	= Reference coarse	2.1.6
[214]...[229]	= no function	
[230]	= Selection DA source	1.1.2
[231]	= Selection DA output	7.1.1
[232], [233]	= no function	
[234]	= Source for Smin DA	7.2.5/7.3.5
[235]	= Source for Smax DA	7.2.6/7.3.6
[236]	= Unit address	3.0.1
[237]	= Baudrate (RS232)	3.0.2
[238]	= Stopbits (RS232)	3.0.3
[239]	= Parity (RS232)	3.0.4
[240]	= Protocol (RS232)	3.0.5
[241]...[248]	= no function	
[249], [250]	= Function input 1...2	4.0.1/4.0.2
[251]	= no function	
[252]...[255]	= Function output1...4	5.0.1...5.0.4
[256]...[267]	= Camfunction	6.1.1...6.12.1
[268]...[279]	= assign cam to output	6.1.8...6.12.8
[280]...[291]	= Source cam	6.1.2...6.12.2
[292]...[393]	= Source for cam end	6.1.4...6.12.4
[304]...[315]	= Source for cam begin/limit value	6.1.3...6.12.3
[316]...[399]	= no function	

AP20 COUNTER

6 Connections

Connections on the rear




6.1 Overview clamp connections

1. +10...+35V supply
2. 0V supply
3. K1 or counting dir.
4. /K1 or counting dir.
5. K2 or counting pulse
6. /K2 or counting pulse
7. Input-1
8. Input-2
9. common for inputs (0V)
10. +10...35V DC supply output for sensor
11. +5V DC supply output for sensor
12. 0V for sensor
13. TxD
14. RxD
15. Output -1
16. Output -2
17. Output -3
18. Output -4
19. 0V for outputs
20. +U for outputs

21. 0V analog
22. U-out
23. I-out


AP20 COUNTER

6.2 Supply




AP20 COUNTER

6.3 Counting input




6.4 Encoder 5V with inverted signals




AP20 COUNTER

6.5 Encoder 5V without inverted signals




6.6 Encoder 10 – 30V




CAUTION!
When using 24 V encoders don't connect terminal 4 and 6.

AP20 COUNTER

6.7 Digital inputs




6.8 Digital outputs




AP20 COUNTER

6.9 RS232



6.10 Analog output



AP20 COUNTER

7 Technical specifications


7.1 Specifications

- Supply voltage	10...35V DC (power failure not active) 16...35V DC (power failure active)
current consumption	< 150mA
- Output voltage	for external encoder
+UD	max 400mA depending on supply voltage
+5V	max 400mA
- Processor	
μController	XC167
Data memory	EEPROM
Cycle time	250μS (fixed)
Counting range	-9999999...+99999999
- Counting input	optically isolated
signal level	low (5V): 0...+0.8V high (5V): +2.8V...+5V low (24V): 0...+5V high (24V): +15V...+35V
voltage output	5,3V max. 350mA
input resistor	appr. 3kOhm at 24V appr. 0.35kOhm at 5V
input frequency	max. 150 kHz
- Digital inputs 1...2	optically isolated
input resistor	low: 0...+5V high: +10V...+35V appr. 1.8kOhm at 24V
- Digital outputs 1...4	optically isolated, N FET, short-circuit proof
Imax	500 mA (min load 200 μA)
Supply voltage	35V max.
- Voltage output	galvanically isolated
range	max. -10V ... +10V
resolution	305 μV
offset-temp. coeff.	< 20 ppm/ °C
Imax	+/-12mA
- Current output	galvanically isolated
range	max. -20mA ... +20mA
resolution	610 μA
offset-temp. coeff.	< 20 ppm/ °C
Rmax	550 Ohm
- Serial communication	RS232 C
- Display	8 decades 7-segments LED
digit height	14 mm
- Temperature range	0...50°C
- Connection diameter	1,6 mm ² (raster 3,81mm)
- Electromagnetic compatibility	in accordance with guideline
emission	2004/108/EC
immunity	NEN-EN-IEC61000-6-3:2007 NEN-EN-IEC61000-6-3:2005
- Weight	< 0.25 kg
- Sealing	front IP50, with protective hood IP54, rear IP20

AP20 COUNTER


7.2 Typekey

AP20- X X




7.3 Dimensions AP20

Side view




Top view




AP20 COUNTER

Dimensions EMC bracket type EMC-B02

With RS232 (9P sub-D) on EMC bracket




Side view with EMC bracket




AP20 COUNTER

7.3.1 Connections RS232 on 9P sub-D connector



7.4 Dimensions protective hood type CDS-B02



AP20 COUNTER

Contact

FRABA America
T +1 609 750-8705
info@posital.com

FRABA Europe
T +49 221 96213-0
info@posital.eu

FRABA Asia
T +65 6514 8880
info@posital.sg

The picture and drawing are for general presentation purposes only. Please refer to the "Download" section for detailed technical drawings. All dimension in [inch] mm.

© FRABA B.V., All rights reserved. We do not assume responsibility for technical inaccuracies or omissions. Specifications are subject to change without notice.